

FUEL SYSTEM

	Page
FUEL PUMP	
DISASSEMBLY	8-2
INSPECTION	8-3
ASSEMBLY	8-3
CARBURETOR (FOR 18R ENGINE)	
For South Africa	
CARBURETOR CIRCUITS.....	8-5
DISASSEMBLY	8-6
INSPECTION	8-9
ASSEMBLY	8-12
ADJUSTMENT	8-18
CARBURETOR (FOR 18R ENGINE)	
Except South Africa	
CARBURETOR CIRCUITS.....	8-21
DISASSEMBLY	8-22
INSPECTION	8-32
ASSEMBLY	8-36
ADJUSTMENT	8-45
CARBURETOR (FOR 18R-G ENGINE)	
CARBURETOR CIRCUITS.....	8-55
DISASSEMBLY	8-56
INSPECTION	8-59
ASSEMBLY	8-61

FUEL PUMP

DISASSEMBLY

Disassemble in numerical order.

Fig. 8-1






Fig. 8-2



Mark the position of pump cover and upper body.

8-3

**INSPECTION**

Inspect diaphragms for tear and check valves for defective operation. Replace if damaged.

ASSEMBLY

Assemble in numerical order.

8-4





Fig. 8-5



Assemble lower and upper body in direction shown.



Fig. 8-6



Assemble upper body and cover over the diaphragm.
Inlet and outlet chamber separating walls should be aligned.



CAP
For 3
CARE


Fig. 8-7

CARBURETOR (FOR 18R ENGINE)

For South Africa

CARBURETOR CIRCUITS

Fig. 67



- | | | | |
|---|-----------------|----|------------------------------|
| 1 | Pump Plunger | 10 | Needle Valve |
| 2 | 2nd Main Nozzle | 11 | 2nd Main Jet |
| 3 | Pump Jet | 12 | Thermostatic Valve |
| 4 | Choke Valve | 13 | Diaphragm |
| 5 | 1st Main Nozzle | 14 | 2nd Throttle Valve |
| 6 | Solenoid Valve | 15 | 1st Throttle Valve |
| 7 | Slow Jet | 16 | Idle Mixture Adjusting Screw |
| 8 | Power Piston | 17 | 1st Main Jet |
| 9 | Float | 18 | Power Valve |

DISASSEMBLY

Air Horn

Disassemble in numerical order.

Fig. 8-8






Fig. 8-9



Lift out air horn.


Assemble in numerical order.

Fig. 8-10



- | | | | |
|---|---------------------------|----|--------------------------------------|
| 1 | Float | 6 | Coil Housing & Plate |
| 2 | Needle Valve Sub-assembly | 7 | Sliding Rod & Fast Idle Cam Follower |
| 3 | Pump Plunger | 8 | Vacuum Piston & Connector |
| 4 | Power Piston & Spring | 9 | Choke Shaft |
| 5 | Choke Valve | 10 | Thermostat Case |

Fig. 8-11




File off the set screw ends and remove the choke valve.

Body

Disassemble in numerical order.

Fig. 8-12



INSPECTION

Precaution —

Before inspecting the parts, wash them thoroughly in gasoline. Using compressed air, blow all dirt and other foreign matter from the jets and similar parts, and from the fuel passages and apertures in the body.

2. Never clean the jets or orifices with wire or a drill. This could enlarge the openings and result in excessive fuel consumption.

Fig. 8-13




Inspect the following parts and replace any part damaged.

Air Horn Parts


1. Air horn: Cracks, damaged threads, and wear on choke shaft bores.

Fig. 8-14



2. Float: Broken lip, wear in float pivot pin holes.
3. Needle valve: surface contacting valve seat.
4. Strainer: Rust, breaks.
5. Power piston: Scratches, excessive wear. Power piston spring broken or deformed.

Fig. 8-15



6. Vacuum piston: Defective sliding of piston, carbon adhering to the inside thermostat case.
7. Choke valve: Deformation. Choke shaft worn, bent, or not fitting properly into housing.

Fig. 8-16




Fig. 8-17




Fig. 8-18





Fig. 8-19



Body Parts

1. Body: Cracks, scored mounting surfaces, damaged threads.



2. Jets: Damaged contacting surface or threads. Screwdriver slots.
3. Power valve: Faulty opening and closing action. Clogged. Damaged contacting surface or threads.




4. Venturi: Clogged or damaged.



5. Pump damping spring: Deformation, rust.
6. Pump check ball: Damaged, rusted.
7. Pump plunger: Wear at sliding surface, deformed or damaged leather.

Fig. 8-20



8. Secondary diaphragm: Damaged.


Fig. 8-21



Flange Parts


1. Flange: Cracks, injured mounting surfaces, damaged threads, wear at throttle shaft bearings.
2. Throttle valves: Wear or deformation in valves. Wear, bending, twisting, or faulty movement inside housing of shaft.

Fig. 8-22



3. Idle mixture adjusting screw: Damage at tapered tip or threads.

Fig. 8-23



Solenoid Valve

Check operation of solenoid valve. Connect wiring to the battery positive terminal and ground the body. The needle valve should be pulled in.

ASSEMBLY

Air Horn

Assemble in numerical order.

Fig. 8-24






Fig. 8-25



Assemble the vacuum piston in the direction as shown.


Fig. 8-2

Fig. 8-26




Install the choke valve andpeen the screws.

Fig. 8-27



Align the bimetal with the choke shaft when installing the housing.


Fig. 8-28



Align the case scale center line against the housing scale line.

Check the choke valve to see that it will close completely when released from fully open position. (Atmospheric temperature below 25°C or 77°F).

Fig. 8-29




Install power piston and spring. Make sure that the piston moves smoothly.

Fig. 8-30



Fit on needle valve, spring and push pin in order.

Fig. 8-31



Adjust float level.


Allow the float to hang down by its own weight. Then check the clearance between the float tip and air horn with SST [09240-00012]. Adjust by bending the (A) part of float lip.

Standard **3.5 mm (0.14 in)**

—Note—

This measurement is always made without any gasket on air horn.

Fig. 8-32



Adjust lowered position.


Lift up the float and check the clearance between the needle valve plunger and float lip with SST [09240-00012]. Adjust by bending the (B) part of float lip.

Standard **1.0 mm (0.04 in)**

Body

Assemble in numerical order.


Fig. 8-33



- 1 Level Gauge Glass
- 2 First Main Jet
- 3 Second Main Jet
- 4 Solenoid Valve
- 5 Diaphragm Sub-assembly
- 6 Thermostatic Valve
- 7 Second Small Venturi

- 8 First Small Venturi
- 9 Power Valve
- 10 Slow Jet
- 11 Pump Damping Spring & Steel Ball
- 12 Pump Discharge Weight & Steel Ball
- 13 Lever (For T.P.)

Fig. 8-34



Install main jets over gasket.


Primary jet

Brass colored

Secondary jet


Chrome colored

Fig. 8-35



Assemble secondary diaphragm in order as shown.

Fig. 8-36



Install pump outlet ball and weight.

— Note —

There are two sizes of balls.

Larger ball: For Pump outlet.

Smaller ball: For Pump inlet.

Body And Air Horn

Assemble in numerical order.

Fig. 8-37





Fig. 8-38



Assemble body and air horn over new gasket. Take care not to damage pump plunger leather.

Fig. 8-39




Fig. 8-40




Fig. 8-41





Fig. 8-42



ADJUSTMENT

Use SST [09240-00014 and 09240-00020] to make adjustments.

- Throttle valve openings**
Open the primary and secondary throttle valves separately and check if the throttle valves will be perpendicular to the flange surface when fully opened. Adjust by bending the respective throttle lever stoppers at the primary (1) and secondary sides (2).
- Kick up**
Adjust the clearance between the second throttle valve and body by bending the second throttle lever (1).
With first throttle valve opening
 $64 \sim 90^\circ$
Standard clearance
0.2 mm (0.0079 in)
- Fast idle**
With choke valve fully closed, check the clearance between bore and primary throttle valve. Adjust by turning fast idle adjusting screw (1).
Standard clearance
0.91 mm (0.036 in)

Fig. 8-43




Fig. 8-44



Fig. 8-45





Fig. 8-46



4. Unloader

With the first throttle valve fully opened, adjust the choke valve angle by bending the fast idle-cam follower or choke shaft lip (1).

Standard angle **47° from bore**

b. Automatic choke

(1) Set the coil housing scale mark so that it will be aligned with the center line of the thermostat case.

— Note —

The choke valve becomes fully closed when atmospheric temperature reaches 25°C (77°F).

(2) Depending on the vehicle operating conditions, turn the coil housing and adjust the engine starting mixture.

If too rich Turn clock-wise.

If too lean Turn counterclock-wise.

— Note —


One graduation of thermostat case scale equals 5°C (9°F) change.

6. Fully screw in the idle mixture adjusting screw and then unscrew it about 2-1/2 turns.

— Note —

Be careful not to damage the screw tip by tightening the screw too tight.

Fig. 8-47



7. Accelerating pump
Adjust the pump stroke by bending part (A).

Standard 4.5 mm (0.177 in)


— Note —

After adjustment is made, be sure to check the linkage to see that it operates smoothly.


CARBURETOR (FOR 18R ENGINE) Except South Africa

CARBURETOR CIRCUITS


Fig. 8-50



- | | | | |
|----|-------------------------|----|---------------------------------|
| 1 | AAP Outlet Check Valve | 15 | Needle Valve |
| 2 | Hot Idle Compensator | 18 | AAP Diaphragm |
| 3 | Pump Plunger | 17 | AAP Inlet Check Valve |
| 4 | Second Slow Jet | 18 | Second Main Jet |
| 5 | Second Main Jet | 19 | Second Throttle Valve Diaphragm |
| 6 | Choke Valve | 20 | Second Slow Port |
| 7 | First Main Jet | 21 | Second Throttle Valve |
| 8 | First Main Air Bleed | 22 | First Throttle Valve |
| 9 | Second Slow Air Bleed | 23 | First Slow Port |
| 10 | Fuel Cut Solenoid Valve | 24 | Idle Nozzle |
| 11 | First Slow Air Bleed | 25 | Idle Mixture Adjusting Screw |
| 12 | First Slow Jet | 26 | First Main Jet |
| 13 | Power Piston | 27 | Power Valve |
| 14 | Float | | |




[AUTOMATIC CHOKE]



[MANUAL CHOKE]

Fig. 8-51



Use SST [09860-11011] for carburetor servicing.

DISASSEMBLY

Air Horn

Disassemble in numerical order.

Fig. 8-52




Fig. 8-53




Remove "E" washer with a small screwdriver.

Fig. 8-54




Disconnect pump connecting link from throttle shaft lever.

Fig. 8-55



Gradually loosen air horn set screw in 2 or 3 stages in diagonal order.

Fig. 8-56



Lift out air horn.

Float

Disassemble in numerical order.

Fig. 8-57





Fig. 8-58



Remove needle valve seat with SST [09860 11011].

Fig. 8-59

**Air Horn**

Before disassembling, check following items.

1. Measure heating coil resistance with ohmmeter.

Resistance **7.5 — 10.0 Ω**

Fig. 8-60



2. Check choke valve action.


Fig. 8-61



3. Check choke breaker diaphragm action.

Automatic choke

Fig. 8-62




Manual choke


Disassemble in numerical order.

Fig. 8-63

AUTOMATIC CHOKE




MANUAL CHOKE



Body


Disassemble in numerical order.

Fig. 8-64




- | | | | |
|---|--------------------------------------|----|---------------------------------|
| 1 | 1st Air Bleed Jet | 9 | First Main Jet |
| 2 | 2nd Air Bleed Jet | 10 | First Small Venturi |
| 3 | Slow Jet | 11 | Second Small Venturi |
| 4 | Main Air Bleed | 12 | AAP Diaphragm |
| 5 | Pump Discharge Weight & Outlet Valve | 13 | Solenoid Valve |
| 6 | AAP Outlet Valve | 14 | Second Throttle Valve Diaphragm |
| 7 | Power Valve | 15 | Fast Idle Cam |
| 8 | Second Main Jet | | |

Fig. 8-65




Remove 1st and 2nd slow air bleed jet with SST [09860-11011].

Fig. 8-66




Remove slow jet plug with SST [09860-11011].

Fig. 8-67




Remove slow jet with SST [09860-11011].

Fig. 8-68




Remove 1st main air bleed with SST [09860-11011].

Fig. 8-69




Remove discharge weight plug with SST [09860-11011], then remove discharge weight and outlet check valve.

Fig. 8-70



Remove AAP outlet valve plug with SST [09860-11011], then remove spring and outlet check valve.

Fig. 8-71



Remove power valve with SST [09860-11011].

Fig. 8-72



Remove 1st, 2nd main jet and gaskets.

Fig. 8-73



Remove snap ring, strainer and inlet check valve.

Fig.

Flang

Disas

Fig. 8-



Fig. 8-



Fig. 8-



Flange

Disassemble in numerical order.

Fig. 8-74





Fig. 8-75



Remove bolt and nut from body.

Fig. 8-76



Remove bolt from flange.

INSPECTION

— Precaution —

1. Before inspecting the parts, wash them thoroughly in gasoline. Using compressed air, blow all dirt and other foreign matter from the jets and similar parts, and from the fuel passages and apertures in the body.
2. Never clean the jets or orifices with wire or a drill. This could enlarge the openings and result in excessive fuel consumption.


Fig. 8-77



Air Horn Parts


1. Make sure that power piston moves smoothly.

Fig. 8-78




2. Check float and pivot pin for wear or broken.

Fig. 8-79




3. Strainer: Rust, breaks.
4. Needle valve surface.
5. Needle valve seat.

Fig. 8-80

**Body Parts**


1. Body
Cracks, scored mounting surfaces, damaged threads.

Fig. 8-81




2. Venturi
Damaged or clogged.

Fig. 8-82




3. Jets
Damaged or clogged.
Damaged contact surface or threads.
Screwdriver slots.

Fig. 8-83




4. Power valve
Faulty opening and closing action.
Clogged.
Damaged contact surface or threads.

Fig. 8-84




5. Acceleration pump
 Pump damping spring: Deformation, rust.
 Pump check ball: Damaged, rusted.
 Pump plunger: Wear at sliding surface, deformed or damaged leather.

Fig. 8-85




6. Auxiliary acceleration pump
 Diaphragm damaged.

Fig. 8-86




7. Secondary diaphragm
 Damaged.

Fig. 8-87

**Flange Parts**


1. Flange: Cracks, injured mounting surfaces, damaged threads, wear at throttle shaft bearings.

Fig. 8-88




2. Throttle valves: Wear or deformation in valves. Wear, bending, twisting, or faulty movement inside housing of shaft.

Fig. 8-89



3. Idle mixture adjusting screw: Damage at tapered tip or threads.

Fig. 8-90

**Solenoid Valve**

1. Check operation of solenoid valve. Connect wiring to the battery positive terminal and ground the body. The needle valve should be pulled in.
2. Check needle valve "A" part.

ASSEMBLY

Assemble in numerical order.

Fig. 8-91





Fig. 8-92



Tighten bolt and nut.

Fig. 8-93




Tighten bolt.

Body

Assemble in numerical order.


Fig. 8-94



- 1 Fast Idle Cam
- 2 Second Throttle Valve Cam
- 3 Solenoid Valve
- 4 AAP Diaphragm
- 5 Second Small Venturi
- 6 First Small Venturi
- 7 Main Air Bleed
- 8 Power Jet

- 9 Second Air Bleed Jet
- 10 First Air Bleed Jet
- 11 Slow Jet
- 12 Pump Discharge Weight & Outlet Valve
- 13 AAP Outlet Valve
- 14 Second Main Jet
- 15 First Main Jet

Fig. 8-95



Install main jets over gasket

First jet

Brass colored

Second jet


Chrome colored

Fig. 8-96



Tighten first and second main jets with SST [09860-11011].

Fig. 8-97




Install jets, air bleed, valve and plugs as shown.

Air Horn

Assemble in numerical order.

Fig. 8-98


AUTOMATIC CHOKE



- 1 Choke Valve Shaft
- 2 Choke Valve
- 3 Lever
- 4 Relief Lever
- 5 Choke Breaker
- 6 Thermostat Case & Gasket
- 7 Choke Lever
- 8 Coil Housing


Fig. 8-99
Fig. 8-100
Fig. 8-101

MANUAL CHOKE




- 1 Choke Valve Shaft
- 2 Choke Valve
- 3 Lever
- 4 Relief Lever
- 5 Choke Breaker
- 6 Spring
- 7 Choke Shaft Lever & Spring
- 8 Snapping
- 9 Nut & Lever

Fig. 8-99




Hook lever to bi-metal spring.

Fig. 8-100



Align case scale standard line against housing scale line.

Fig. 8-101



Check choke valve action.

Float

Assemble in numerical order.

Fig. 8-102





Fig. 8-103



Tighten needle valve seat with SST [09860-11011].

Fig. 8-104



Adjust float level.


Allow the float to hang down by its own weight. Then check the clearance between the float tip and air horn with SST [09240-00014]. Adjust by bending the (A) part of float lip.

Standard	10.0 – 11.0 mm
	(0.39 – 0.43 in)

— Note —


This measurement is always made without any gasket on air horn.

Fig. 8-105



Adjust by bending float lip as shown.

Fig. 8-106



Adjust lowered position.

Lift up the float and check the clearance between the needle valve plunger and float lip with SST [09240-00020]. Adjust by bending the (B) part of float lip.

Standard	1.0 – 1.2 mm
	(0.039 – 0.047 in)


Fig. 8-107



Adjust by bending float lip as shown.

Body And Air Horn

Assemble in numerical order.

Fig. B-108


- 1 Air Horn
- 2 Pump Lever & Connecting Rod
- 3 "E" Washer
- 4 Clip
- 5 Throttle Lever Return Spring

Fig. 8-109




Before assembling air horn, pump damping spring and plunger.

Fig. 8-110




Put on gasket on air horn and install needle valve and float.

Fig. 8-111



Tighten the air horn set screws at little at a time in diagonal order.

Fig. 8-112

**ADJUSTMENT**


Use SST [09240-00014 and 09240-00020] to make adjustments.

Fig. 8-113



1. First throttle valve opening.
 - (1) Fully open first throttle valve.


Fig. 8-114



- (2) Check first throttle valve opening angle:

Opening Angle **90°**

Fig. 8-115



- (3) Adjust by bending throttle lever stopper.

Fig. 8-116




2. Second throttle valve opening
 (1) Fully open first throttle valve.

Fig. 8-117



- (2) Fully open second throttle valve lever.

Fig. 8-118




- (3) Check throttle valve opening angle.
Opening Angle 90°

Fig. 8-119



- (4) Adjust by bending throttle lever stopper.

Fig. 8-120



3. Seco-touch angle:

- (1) Open first throttle valve until throttle valve lever "A" part touch "B" part.


Fig. 8-121



- (2) At this time, check first throttle valve opening angle.


Seco-touch Angle 57 - 61°

Fig. 8-122



- (3) Adjust by bending "A" part.

Fig. 8-123



4. Kick up

- (1) Open first throttle valve until kick arm slightly open second throttle valve.

Fig. 8-124




- (2) Check clearance between second throttle valve and body.

Kick up clearance

0.1 – 0.2 mm


(0.004 – 0.008 in)

Fig. 8-125



- (3) Adjust by bending "A" part.


Fig. 8-126



5-1. Fast idle (only automatic choke)

- (1) Fully close choke valve by turning coil housing.

Fig. 8-127



- (2) Slightly open the first throttle valve and then close it. Insure that the throttle lever "A" part hooks to the fast idle cam.

Fig. 8-128




- (3) Check clearance between first throttle valve and bore.

Fast idle clearance

0.81 mm (0.032 in.)

Fig. 8-129



- (4) Adjust by turning fast idle adjusting screw.


Fig. 8-130



5-2. Fast idle (only manual choke)

- (1) Fully close choke valve by turning choke shaft lever.

Fig. 8-131



- (2) Check clearance between first throttle valve and bore.

Fast idle clearance

1.01 mm (0.039 in.)

Fig. 8-132



- (3) Adjust by turning fast idle adjusting screw.

Fig. 8-133



6. Unloader (only automatic choke)
(1) Fully close choke valve by turning coil housing.

Fig. 8-134



- (2) Fully open first throttle valve.


Fig. 8-135



- (3) At this time, check choke valve opening angle.


Unloader Angle 47°

Fig. 8-136



(4) Adjust by bending "A" part.

Fig. 8-137



7-1. Choke breaker (only automatic choke)

(1) Fully close choke valve by turning coil housing.


Fig. 8-138



(2) Connect hose to diaphragm and suck hose with mouth.


(3) At this time, check clearance between choke valve and bore.

Fig. 8-139



(4) Adjust by bending "A" part.


Fig. 8-140



7-2. Choke breaker (only manual choke)

- (1) Fully close choke valve by turning choke lever.

Fig. 8-141



- (2) Connect hose to diaphragm and suck hose with mouth.

- (3) At this time, check clearance between choke lever, and bore.

Fig. 8-142



- (4) Adjust by bending "A" part.

Fig. 8-143




B. Automatic choke:

- (1) Set the coil housing scale mark so that it will be aligned with the center line of the thermostat case.

— Note —

The choke valve becomes fully closed when atmospheric temperature reaches 25° C (77° F).


Fig. 8-144



- (2) Depending on the vehicle operating conditions, turn the coil housing and adjust the engine starting mixture.

If too rich Turn clock-wise.
If too lean ... Turn counterclock-wise.

Fig. 8-145



9. Idle mixture adjusting screw.
Tighten the idle mixture adjusting screw and then unscrew it about three turns.

— Note —

Be careful not to damage the screw tip by tightening the screw too tightly.

Fig. 8-146




10. Accelerating pump
Adjust the pump stroke by bending part (A)

Standard	Europe	3.7 mm (0.146 in)
	Australia General	3.8 mm (0.150 in)

— Note —


After adjustment is made, be sure to check the linkage to see that it operates smoothly.



CARBURETOR(FOR 18R-G ENGINE)

CARBURETOR CIRCUITS

Fig. 8-150



- 1 Idle Speed Adjusting Screw
- 2 Screw (For Float Adjustment)
- 3 Needle Valve Sub-assembly
- 4 Float Sub-assembly
- 5 Strainer
- 6 Main Air Bleed Jet
- 7 Main Air Bleed Tube
- 8 Slow Jet
- 9 Idle Mixture Adjusting Screw


- 10 Air Bleed Tube
- 11 Starter Disc
- 12 Inner Venturi
- 13 Main Jet
- 14 Diaphragm Rod Sub-assembly
- 15 Throttle Valve
- 16 Pump Valve Weight
- 17 Pump Valve Check Ball

DISASSEMBLY

Bowl Cover

Disassemble in numerical order.


Fig. 8-151



Body

Disassemble in numerical order.


Fig. 8-152



- 1 Float Chamber Plate
- 2 Main Air Bleed Jet
- 3 Main Jet Holder
- 4 Slow Jet
- 5 Starter Jet
- 6 Pump Nozzle
- 7 Pump Check Valve


- 8 Idle Mixture Adjusting Screw
- 9 Pump Rod
- 10 Accelerating Pump
- 11 Sleeve
- 12 Small Venturi
- 13 Large Venturi

Fig. 8-153




Remove the set screw and take out the sleeve.

Fig. 8-154



Remove the set screw and take out the small venturi.

Fig. 8-155



Remove the set screw and take out the large venturi.

INSPECTION


— Precaution —

1. Before inspecting the parts, wash them thoroughly in gasoline. Using compressed air, blow all dirt and other foreign matter from the jets and similar parts, and from the fuel passages and apertures in the body.



2. Never clean the jets or orifices with wire or a drill. This could enlarge the openings and result in excessive fuel consumption.

Fig. 8-156




Inspect the following parts and replace any part damaged.

Bowl Cover Parts

1. Bowl cover: Cracks, damaged threads.
2. Starter pipe: Damaged and/or clogged.

Fig. 8-157




3. Filter: Clogged, rusted, or damaged.

— Note —


New gasket must always be used whenever the union is removed.

Fig. 8-158




4. Starter disc: Damaged or worn sliding surface.

Fig. 8-159



- b. Needle valve: Contacting valve seat.
6. Float: Deformed, wear in float lever pin holes, bent float arms.


Fig. 8-160



Body Parts


1. Body: Cracks, damaged mounting surfaces and threads, wear on throttle shaft bearings, and carbon adherence.
2. Throttle valves: Wear or deformation in valves. Wear, bending, twisting, or faulty movement inside housing of shaft.

Fig. 8-161



3. Jets: Clogging, damage to contacting surface, threads and screwdriver slots.
4. Idle mixture adjusting screw: Damage to tapered tip or threads.

Fig. 8-162




5. Pump diaphragm: Damaged.
6. Pump body: Cracks, damaged mounting surfaces.
7. Pump nozzle: Clogged and/or damaged.

ASSEMBLY

Body

Assemble in numerical order.


Fig. 8-163



- 1 Large Venturi
- 2 Small Venturi
- 3 Sleeve
- 4 Accelerating Pump
- 5 Pump Rod
- 6 Idle Mixture Adjusting Screw
- 7 Pump Check Valve


- 8 Pump Nozzle
- 9 Starter Jet
- 10 Slow Jet
- 11 Main Jet Holder
- 12 Main Air Bleed Jet
- 13 Float Chamber Plate

Fig. 8-164




Using the longest screw, assemble the small venturi as shown.

Fig. 8-165




Assemble the accelerating pump in numerical order as shown.

Fig. 8-166



Install the cotter pin in the third hole from the tip of pump rod.

Fig. 8-167



Screw out 1 turn from fully closed position.


— Note —

Take care not to mistake the left and right sides.

Bowl Cover

Assemble in numerical order.


Fig. 8-168



- 1 Needle Valve Sub-assembly
- 2 Float Adjusting Stay
- 3 Starter Disc
- 4 Bowl Cover Gasket
- 5 Float

- 6 Bowl Cover Sub-assembly
- 7 Jet Chamber Cover
- 8 Fuel Union
- 9 Starter Back Spring

Fig. 8-170



Preset the float position.

About 16 mm (0.63 in) from bowl cover lower surface.

Fig. 8-169



Adjust the float position as shown, if necessary.