

STARTING SYSTEM

	Page
CONVENTIONAL STARTING SYSTEM CIRCUIT	7-2
PERFORMANCE TEST	7-3
CONVENTIONAL STARTER	7-6
REDUCTION STARTING SYSTEM CIRCUIT	7-23
PERFORMANCE TEST	7-24
REDUCTION STARTER	7-26

CONVENTIONAL STARTING SYSTEM CIRCUIT

Fig. 7-1




Fig. 7-2





Fig. 7-3




PERFORMANCE TEST



NO-LOAD PERFORMANCE TEST

1. Secure the starter in a vise to prevent an accident.

Fig. 7-4



2. Connect the starter to a battery as shown in the figure.

Positive side


Battery (+) —————> Ammeter (+)

Ammeter (-) —————> Terminal 30

Negative side

Battery (-) —————> Starter body


Fig. 7-5



3. Connect the terminal 50.
If the starter shows smooth and steady rotation with the pinion jumping out and drawing less than specified current, it is satisfactory.

**Specified Current: Less than 50A
(at 11V)**

Fig. 7-6



MAGNETIC SWITCH TEST




– Caution –

Each test must be performed within a short time (3 – 5 seconds) to prevent the coil from burning out.

1. Disconnect the terminal C lead wires.

Fig. 7-7



2. Pull-in test
Connect the magnetic switch to a battery as shown in the figure.

Negative side


Battery (-) → Starter body and terminal C

Positive side

Battery (+) → Terminal 50


If the pinion has definitely jumped out, the pull-in coil is satisfactory.

Fig. 7-8




3. Hold-in test
Disconnect terminal C. The pinion should remain projected.

Fig. 7-9



4. Check the plunger return.
When disconnecting the switch body, the pinion should return quickly.

Fig. 7-10




5. Check pinion clearance.
(1) Connect the field coil lead to terminal C.
(2) Connect the magnetic switch to a battery as shown in the figure.

Positive side

Battery (+) → Terminal 50

Battery (-) → Starter body

Fig. 7-11




- (3) Move the pinion to the armature side to eliminate slack, and check the clearance between the pinion end stop collar.

Clearance:

0.1 – 4.0 mm

(0.004 – 0.157 in.)

Fig. 7-12



- (4) For 1.0 kw
If necessary, loosen the lock nut and adjust.

Clearance

Stud


Too large —————> Screw in

Too small —————> Screw out


CONVENTIONAL STARTER CUTAWAY VIEW

Fig. 7-13

[0.8 kw Type]



[1.0 kw Type]




DISASSEMBLY

1. Disassemble the parts in the numerical order shown in the figure.

Fig. 7-14

[0.8 kw Type]




- | | |
|--------------------------------|-----------------------------|
| 1. Terminal Cover | 8. Brush Holder |
| 2. Magnetic Switch Set Nut | 9. Yoke |
| 3. Magnetic Switch Assembly | 10. Drive Lever |
| 4. Bearing Cover | 11. Armature |
| 5. Lock Plate, Spring & Rubber | 12. Drive Housing |
| 6. Bolt | 13. Snap Ring & Stop Collar |
| 7. Commutator End Frame | 14. Clutch with Pinion Gear |

2. Disassemble the parts in the numerical order shown in the figure.


Fig. 7-15

[1.0 kw Type]




- | | |
|--------------------------------|--|
| 1. Magnetic Switch Set Bolt | 9. Seal |
| 2. Magnetic Switch Assembly | 10. Bolt |
| 3. Bearing Cover | 11. Drive Housing |
| 4. Lock Plate, O Ring & Rubber | 12. Drive Lever |
| 5. Bolt | 13. Armature |
| 6. Commutator End Frame | 14. Snap Ring & Stop Collar |
| 7. Brush Holder | 15. Clutch with Pinion Gear |
| 8. Yoke | 16. Spring, Spring Holder & Center Bearing |

Fig. 7-16




Disconnect the terminal C lead wire from the magnetic switch.

Fig. 7-17



Remove the magnetic switch as shown in the figure.

Fig. 7-18




Measure the armature shaft thrust clearance.

Thrust clearance:

STD 0.05 – 1.00 mm
(0.0020 – 0.0394 in.)


Limit 1.00 mm
(0.0394 in.)

Fig. 7-19




Remove the brushes from the brush holder.

Fig. 7-20




Tap in the stop collar with a screwdriver.

Fig. 7-21




Pry off the snap ring with a screwdriver and remove the stop collar.

Fig. 7-22



If the pinion was difficult to pull out, smoothen the shaft with an oil stone.

Fig. 7-23




INSPECTION & REPAIR

Commutator

Check for following items and repair or replace, if necessary.

1. Dirty or burnt surface
Correct with sandpaper if necessary.

Fig. 7-24




2. Depth of segment mica

Mica depth:

STD 0.4 – 0.8 mm
(0.016 – 0.031 in.)

Limit 0.2 mm
(0.008 in.)


Fig. 7-25



3. Repair the segment mica


(1) If the mica depth is below the limit, correct with a hacksaw blade.

Fig. 7-26




(2) Smooth out the edges with a hacksaw blade.

Fig. 7-27



(3) Use #400 sandpaper to smooth the commutator surface.

Fig. 7-28




4. Runout
Correct on a lathe if it exceeds the limit.

Runout:

STD **Less than 0.1 mm**
 (0.004 in.)

Limit **0.3 mm**
 (0.012 in.)

Fig. 7-29



5. Surface wear
Replace the armature if below the limit.

Commutator outer diameter:


0.8 kw **STD** **28.0 mm**
 (1.102 in.)

Limit **27 mm**
 (1.06 in.)

1.0 kw **STD** **32.7 mm**
 (1.287 in.)


Limit **31 mm**
 (1.22 in.)

Fig. 7-30

**Armature Coil**


1. Ground test
Check the commutator and armature coil core. If there is continuity, the armature is grounded and must be replaced.

Fig. 7-31




2. Short circuit test
Place the armature on an armature tester and hold a hacksaw blade against the armature core while turning the armature. If the hacksaw blade is attracted or vibrates, the armature is shorted and must be replaced.

Fig. 7-32



3. Solder condition
Check for continuity between the commutator and armature coil.


Fig. 7-33



Field Coil


1. Open circuit test
Check for continuity between the field coil brushes. If there is no continuity, there is an open circuit in the field coil and it should be replaced.

Fig. 7-34



2. Ground test
Check for continuity between the field coil end and field frame. If there is continuity, repair or replace the field coil. (for 1.0 kw)

Fig. 7-35



Brush


Measure the brush length and replace if below the limit.

Brush length:

0.8 kw	STD	16 mm
	Limit	10 mm
1.0 kw	STD	19 mm
	Limit	10 mm

(0.63 in.)
(0.39 in.)
(0.75 in.)
(0.39 in.)

Fig. 7-36

**Brush Spring**


Measure the brush spring load with a pull scale. If the reading is below the specified value, replace the spring.

**Tension: 1.02 – 1.38 kg
(2.2 – 3.0 lb)**

– Note –


Take the pull scale reading at the very instant the brush spring separates from the brush.

Fig. 7-37

**Brush Holder**


Check the insulation between the (–) brush holder and (+) brush holder. Repair or replace, if continuity is indicated.

Fig. 7-38

**Drive Lever**


Check the drive lever and spring for wear. Replace, if necessary.

Fig. 7-39

**Starter Clutch & Pinion Gear**


1. Check the spline teeth for wear or damage. Replace, if necessary.
2. Check the pinion for smooth movement.

Fig. 7-40




3. Check the pinion gear teeth and the chamfer for wear or damage.

Fig. 7-41



4. Rotate the pinion. It should turn freely in clockwise direction but lock when turned counterclockwise.


Fig. 7-42



Magnetic Switch


1. Push in the plunger and release it. The plunger should return quickly to its original position.

Fig. 7-43




2. Pull-in coil open circuit test
Check for continuity between the terminal 50 and terminal C.

Fig. 7-44



3. Hold-in coil open circuit test
Check for continuity between the terminal 50 and switch body.

Fig. 7-45




4. For 1.0 kw
Measure and adjust the distance from the switch mounting surface to the stud end.

Moving stud length:

**STD 34 mm
(1.34 in.)
(Reference only)**


Fig. 7-46



Armature Shaft, Bushing & Center Bearing


1. Inspect the armature shaft, drive housing bushing and end frame bushing for wear or damage.

Fig. 7-47



2. Replace the drive housing bushing and end frame bushing if any contact is suspected.
 - (1) Pry out the bushing cover and press out the bushing.
 - (2) Align the bushing hole with the housing groove and press in a new bushing.

Fig. 7-48



- (3) Ream the bushing to obtain the specified clearance.

Bushing to shaft clearance:

STD

0.035 – 0.077 mm


(0.0014 – 0.0030 in.)

Limit

0.2 mm


(0.008 in.)

Fig. 7-49




- (4) Temporarily assemble the parts.
 (5) Make sure that the armature shaft rotates smoothly.

Fig. 7-50



- (6) Clean the bore, install a new bushing cover and stake the housing at four positions.

Fig. 7-51




3. 1.0 kw Type
 Inspect the spring holder, spring and center bearing for cracks, wear or damage. Replace, if necessary.

ASSEMBLY

1. Assemble the parts in the numerical order shown in the figure.

Fig. 7-52

[0.8 kw Type]




- | | |
|----------------------------|---------------------------------|
| 1. Armature | 8. Commutator End Frame |
| 2. Clutch with Pinion Gear | 9. Bolt |
| 3. Stop Collar & Snap Ring | 10. Lock Plate, Spring & Rubber |
| 4. Drive Housing | 11. Bearing Cover |
| 5. Drive Lever | 12. Magnetic Switch Assembly |
| 6. Yoke | 13. Magnetic Switch Set Nut |
| 7. Brush Holder | 14. Terminal Cover |

2. Assemble the parts in the numerical order shown in the figure.


Fig. 7-53

[1.0 kw Type]




- | | |
|---|---------------------------------|
| 1. Armature | 9. Yoke |
| 2. Center Bearing, Spring Holder & Spring | 10. Brush Holder |
| 3. Clutch with Pinion Gear | 11. Commutator End Frame |
| 4. Stop Collar & Snap Ring | 12. Bolt |
| 5. Drive Lever | 13. Rubber, O Ring & Lock Plate |
| 6. Drive Housing | 14. Bearing Cover |
| 7. Bolt | 15. Magnetic Switch Assembly |
| 8. Seal | 16. Magnetic Switch Set Bolt |

Fig. 7-54




Drive in the snap ring with a 14 mm socket wrench, then fit it into the shaft groove.

Fig. 7-55



Compress the snap ring with a vise. Make sure that the snap ring fits correctly.


Fig. 7-56



Tap the pinion to slide the stop collar onto the snap ring.

Fig. 7-57

0.8 kw Type



Install the drive lever.



— Note —
Assemble the drive lever in the direction shown in the figure.

Fig. 7-58






Fig. 7-59



Assemble the brushes with a bent wire, being careful not to damage them.

Fig. 7-60



Install the lock plate and measure the armature shaft thrust clearance. If clearance exceeds the specified value, correct by increasing the number of shims.


Thrust clearance:

STD 0.05 – 1.00 mm
(0.0020 – 0.0394 in.)

Limit 1.00 mm
(0.0394 in.)

Adjusting shim thickness:
0.5 mm
(0.020 in.)

Fig. 7-61




Install the bearing cover.

– Note –


Refill the cover about 1/4 full with grease.

Fig. 7-62



Hook the magnetic switch onto the drive lever spring from underneath.

Fig. 7-63




Check the pinion clearance.

1. Connect the field coil lead to terminal C.
2. Connect the magnetic switch to a battery as shown in the figure.

Battery (+) — Terminal 50
 Battery (−) — Starter body


Fig. 7-64



3. Move the pinion to the armature side to eliminate the slack, and check the clearance between the pinion end and stop collar.

**Clearance: 0.1 – 4.0 mm
 (0.004 – 0.157 in.)**

Fig. 7-65



4. 1.0 kw Type
 If necessary, loosen the lock nut and adjust.

<u>Clearance</u>	<u>Stud</u>
Too large	→ Screw in
Too small	→ Screw out

REDUCTION STARTING SYSTEM CIRCUIT

Fig. 7-66




Fig. 7-67





Fig. 7-68




PERFORMANCE TEST



NO-LOAD PERFORMANCE TEST

1. Secure the starter in a vise to prevent an accident.

Fig. 7-69



2. Connect the starter to a battery as shown in the figure.

Positive side:


Battery (+) ———→ Ammeter (+)

Ammeter (-) ———→ Terminal 30

Negative side:

Battery (-) ———→ Starter housing

Fig. 7-70




3. Connect the terminal 50. If the starter shows smooth and steady rotation with the pinion jumping out and drawing less than specified current, it is satisfactory.

Specified current:

Less than 90A

(at 11.5 V)

Fig. 7-71



MAGNETIC SWITCH TEST




— Note —

Each test must be performed within a short time (3 – 5 seconds) to prevent the coil from burning out.

1. Disconnect the terminal C lead wire.


Fig. 7-72



2. Pull-in test
Connect the magnetic switch to a battery as shown in the figure.
Negative side:
Battery (-) —→ Starter body and terminal C


Positive side:
Battery (+) —→ Terminal 50
If the pinion has definitely jumped out, the pull-in coil is satisfactory.

Fig. 7-73



3. Hold-in test
Disconnect the terminal C. The pinion should remain projected.

Fig. 7-74




4. Check pinion return.
When disconnecting the cable from the starter housing, the jumped-out pinion should return quickly.


REDUCTION STARTER CUTAWAY VIEW

Fig. 7-75

[1.0 kw Type]



[1.4 kw Type]




DISASSEMBLY

1. Disassemble the parts in the numerical order shown in the figure.

Fig. 7-76

[1.0 kw Type]




- | | |
|------------------------|--------------------|
| 1. Through Bolt | 8. Return Spring |
| 2. Yoke & Armature | 9. Magnetic Switch |
| 3. Felt Washer | 10. End Frame |
| 4. Bolt | 11. Brush Holder |
| 5. Starter Housing | 12. Yoke |
| 6. Clutch & Idler Gear | 13. Armature |
| 7. Steel Ball | |

- Disassemble the parts in the numerical order shown in the figure.


Fig. 7-77

[1.4 kw Type]




- | | |
|-------------------------------------|---------------------|
| 1. Through Bolt | 8. Steel Ball |
| 2. Yoke & Armature | 9. Return Spring |
| 3. Felt Washer | 10. Magnetic Switch |
| 4. O Ring | 11. Brush Holder |
| 5. Bolt | 12. Armature |
| 6. Starter Housing | 13. Yoke |
| 7. Clutch Idler Gear & Drive Pinion | |

Fig. 7-78




Disconnect the terminal C lead wire from the magnetic switch.

Fig. 7-79




1.0 kw Type
Remove the starter housing together with the idler gear and clutch.

Fig. 7-80




1.4 kw Type
Remove the starter housing together with the drive pinion, idler gear and clutch.

Fig. 7-81



Using a magnet, remove the steel ball from the clutch shaft hole.

Fig. 7-82




Remove the brushes from the brush holder.

— Note —

Use care not to damage the brush and commutator. Also avoid getting oil or grease on them.

Fig. 7-83




INSPECTION & REPAIR

Commutator

Check for the following items and repair or replace as necessary.

1. Dirty or burnt surface
Correct with sandpaper if necessary.

Fig. 7-84




2. Depth of segment mica

Mica depth:


STD	0.45 – 0.75 mm (0.0177 – 0.0295 in.)
Limit	0.2 mm (0.008 in.)

Fig. 7-85




3. Repair the segment mica.
 - (1) If the mica depth is below the limit, correct with a hacksaw blade.

Fig. 7-90

**Armature Coil**


1. Ground test
Check the commutator and armature coil core.
If there is continuity, the armature is grounded and must be replaced.

Fig. 7-91




2. Short circuit test
Place the armature on the armature tester and hold a hacksaw blade against the armature core while turning the armature. If the hacksaw blade is attracted or vibrates, the armature is shorted and must be replaced.

Fig. 7-92




3. Solder condition
Check for continuity between the commutator and armature coil.

Fig. 7-93

**Field Coil**


1. Open circuit test
Check for continuity between the lead wire and soldered connection of the field coil brush. If there is no continuity, there is an open circuit in the field coil and it should be replaced.

Fig. 7-94



2. Ground test
Check for continuity between the field coil end and field frame.
If there is continuity, repair or replace the field coil.

Fig. 7-95




Brush

Measure the brush length and replace if below the limit.

Brush length:

1.0 kw STD	13.5 mm (0.531 in.)
Limit	10 mm (0.39 in.)
1.4 kw STD	14.5 mm (0.571 in.)
Limit	10 mm (0.39 in.)

Fig. 7-96




Brush Spring

1. Measure the brush spring load with a pull scale. If the reading is below the specified value, replace the spring.

Tension:

1.0 kw STD	1,445 – 1,955 g (3.2 – 4.3 lb)
Limit	1,200 g (2.6 lb)
1.4 kw STD	1,785 – 2,415 g (3.9 – 5.3 lb)
Limit	1,200 g (2.6 lb)

Fig. 7-97




— Note —

Take the pull scale reading at the very instant the brush spring separates from the brush.

Brush Holder.

1. Check the insulation between the (-) brush holder and (+) brush holder. Repair or replace, if continuity is indicated.

Fig. 7-98




- Using #400 sandpaper, clean and fit the brushes so they make proper contact with the commutator.

— Note —

Secure the armature gear in a vise or such.


Fig. 7-99



Gear


- Check the gears for wear or damage.

Fig. 7-100



- Check the gear teeth for wear or damage. Also inspect the flywheel ring gear for same.

Fig. 7-101



Clutch

Rotate the pinion. It should turn free in clockwise direction but lock when turned counterclockwise.

Fig. 7-102




Fig. 7-103




Fig. 7-104




Fig. 7-105

**Magnetic Switch**

1. Pull-in coil open circuit test
Check for continuity between the terminal 50 and terminal C.



2. Hold-in coil open circuit test
Check for continuity between terminal 50 and the magnetic switch body.




3. Check for wear or damage.

**Bearing**


1. Check the bearing for wear or damage.

Fig. 7-106




2. Replace armature bearing if defective.
 (1) Remove the bearing with SST
 SST [09286-46011]

Fig. 7-107



- (2) Replace the front bearing, and drive
 in the rear bearing with SST.
 SST [09285-76010]

Fig. 7-108



Starter Housing

Inspect for wear or damage.

ASSEMBLY


1. Assemble the parts in the numerical order shown in the figure.

Fig. 7-109

[1.0 kw Type]


— Note —

Use high temperature grease to lubricate bearings and gears in the places shown by arrows in the figure below.




- | | |
|------------------------|---------------------|
| 1. Starter Housing | 8. Yoke |
| 2. Clutch & Idler Gear | 9. Brush Holder |
| 3. Steel Ball | 10. End Frame |
| 4. Return Spring | 11. Felt Washer |
| 5. Magnetic Switch | 12. Yoke & Armature |
| 6. Bolt | 13. Through Bolt |
| 7. Armature | |

Fig. 7-110



Install the clutch and idler gear to the starter housing.

Fig. 7-111




Assemble the brush holder.

— Note —


1. Use care not to damage or get oil on the brushes and commutator.
2. Secure the armature gear in a vise or such.

Fig. 7-112



Match the protrusion of the yoke core with the starter housing notch.

Fig. 7-113



PERFORMANCE TEST (NO-LOAD)

Connect the starter to a battery. If the starter shows smooth and steady rotation with the pinion jumping out and drawing less than specified current, it is satisfactory.

**Specified current: Less than 90A
(at 11.5 V)**


2. Assemble the parts in the numerical order shown in the figure.

Fig. 7-114

[1.4 kw Type]


— Note —

Use high temperature grease to lubricate bearings and gears in the places shown by arrows in the figure below.




- | | |
|--------------------------------------|---------------------|
| 1. Starter Housing | 8. Armature |
| 2. Clutch, Idler Gear & Drive Pinion | 9. Brush Holder |
| 3. Steel Ball | 10. O Ring |
| 4. Return Spring | 11. Felt Washer |
| 5. Magnetic Switch | 12. Yoke & Armature |
| 6. Bolt | 13. Through Bolt |
| 7. Yoke | |

Fig. 7-115




Install the clutch, idler gear and drive pinion to the starter housing.

Fig. 7-116



Align the brush holder tab with the notch in the field frame.

Fig. 7-117




Assemble the brush holder.

— Note —


Use care not to damage or get oil on the brushes and commutator.

Fig. 7-118




Install the O ring around the yoke.

Fig. 7-119



Match the protrusion of the yoke core with the starter housing notch.

Fig. 7-120



PERFORMANCE TEST (NO-LOAD)

Connect the starter to a battery. If the starter shows smooth and steady rotation with the pinion jumping out and drawing less than specified current, it is satisfactory.

**Specified current: Less than 90A
(at 11.5 V)**

